

# Applnit

**Category:** Monitor

**Description:** Sets the system monitor vectors.

**Inputs:**

**Registers:** HL points to the vector table

**Flags:** None

**Others:** None

**Outputs:**

**Registers:** None

**Flags:** appFlags set to value from vector table

**Others:** System monitors initialized

**Registers** All

**destroyed:**

**Remarks:** Format for the vector table:

VecTab:	DW	CXMainPtr
	DW	CXPPutAwayPtr
	DW	CXPutAwayPtr
	DW	CXRedisPtr
	DW	CXErrorEPPtr
	DW	CXSizeWindPtr
	DB	AppFlagsByte

Applnit will set cxPage by inputting the current page that's loaded into the memory bank. If you want to use a different page, you must set cxPage manually after running Applnit.

**Example:**